

**Description**

The pressure gauge in the low fuel supply line for petrol engine (systems with the fuel pump in the tank only)
Should be ordered together with the stand!

Note: Specifications are subject to change.

